


FUB Configuration And LED Description

OSP 700/7000 - OSP U10/U100

Ribbon Cable
Make sure the Red Lead
is up

- Axis control ON (Drive Enable)
- Emergency Stop Monitor
- Axis Power ON
- NC Axis Brake release 1
- NC Axis Brake release 2
- EC Axis Brake release 1
- EC Axis Brake release 2
- Control Power On/ LED
- NC Power ON
- NC Power Off
- Main Breaker Off
- Emergency Stop
- Stopping Of Oscillator



Switch setting For Slave
Station Number and
End of Loop 8 (on)